

Congratulations on purchasing your Australian made high-quality StyleLite<sup>®</sup> products. Here are some handy hints to help with care and maintenance.

## INITIAL SURFACE HARDENING

The StyleLite high gloss surface becomes more scratch resistant over the first few days after the removal of the protective film.

This process can be accelerated by lightly polishing the StyleLite surface immediately after the masking film is removed using Novus No. 1 or Plexus plastic polishes with a clean microfibre cloth.

When the protective film is initially removed, dust may be attracted to StyleLite due to the build-up of static electricity. Using Novus No. 1 will remove the static.

# CLEANING DOs AND DON'Ts

- Clean wet microfibre cloth
  Clean wet chamois
  Naurus Na, 1 polith used un
- Novus No. 1 polish used weekly
- Non abrasive soap and detergent
- 🔗 Warm water

DO

#### DON'T

- 😣 Paper towel
- 🗴 Dry wipe
- Brushes, scourers or scrapers
- & Abrasive cleaners
- x Thinners or Methylated Spirits



### GENERAL CLEANING

Apply Novus No. 1 plastic polish or warm soapy water and wipe using a clean microfibre, soft cloth or damp chamois.

#### **REMOVING MARKS & LIGHT SCRATCHES**

Apply Novus No. 2 or a good quality liquid polish (eg. liquid car polish) and using a damp, clean microfibre or soft cloth, polish in a circular pattern. Then remove polish using General Cleaning procedure above.

### **REMOVING HEAVIER SCRATCHES**

Apply Novus No. 3 or a good quality fine compound polish and using a damp, clean microfibre or soft cloth, polish in back and forth motion at right angles to visible scratches. Then use Removing Marks procedure, then General Cleaning procedure above.

Ensure all polish residues are removed completely from the StyleLite surface.

Low speed electric buffing can also be used to repair marks and scratches. See **stylelite-aca.com** for more information.



For more information on this or any other fact sheet please visit -



